


Measurements

SALZBURG L CONVECTION

 Nordpeis

FIG 1

SALZBURG L CONVECTION = MM




Measurements

SALZBURG L CONVECTION



FIG 2

SALZBURG L CONVECTION EXTENSION BASE = MM




Measurements

SALZBURG L CONVECTION



FIG 3

SALZBURG L CONVECTION + 1 = MM



Measurements

SALZBURG L CONVECTION



FIG 4

SALZBURG L CONVECTION/SALZBURG L CONVECTION EXTENSION BASE
SALZBURG L CONVECTION + 1 = AIR/MM

